

## Technical Bulletin

TB062321-001 : Micro-Loc Twin Back-Mount SRD

## Connecting the SRD to a Harness with 3062-36T Triple Lock Carabiner

This Technical Bulletin affects the following Reliance products:

3062-36T Triple Lock Carabiner 42xxxxx Series Micro-Loc<sup>™</sup> Personal Self Retracting Lanyard

All 42xxxxx Series Micro-Loc<sup>™</sup> Personal Self Retracting Lanyards can be connected directly to the harness webbing at the back D-Ring location utilizing either of the 3062-36T Triple Lock Carabiners (Up to 2 units may be connected to the 3062-36T Triple Lock Carabiner) shown in (Figure 1).





Figure 1

## WARNING!

The carabiner triple lock gate must be closed and the triple lock engaged after assembly. If the carabiner triple lock gate is not properly locked it may result in serious injury or death.

- 1. Locate the back D-Ring and the black back plaque, and rotate D-Ring upwards. (Figure 2)
- 2. Pull both webbing shoulder straps in the back D-Ring into a loop away from the black back plaque. Pull enough slack to create a loop large enough to allow the insertion of the carabiner through the webbing. (Figure 3)
- 3. Open the carabiner and assemble first Micro-Loc<sup>™</sup> Personal Self Retracting Lanyard to the carabiner, rotating the Micro-Loc<sup>™</sup> Personal Self Retracting Lanyard to the bottom of the carabiner body. (Figure 4)
- 4. Pass the carabiner behind the webbing loop. Both shoulder strap webs must be captured by the carabiner. Rotate the carabiner so it is horizontal to the black back plaque. (Figure 5)

- 5. Open the carabiner and assemble the second Micro-Loc<sup>™</sup> Personal Self Retracting Lanyard to the carabiner and close and ensure triple lock is engaged. (Figure 6&7)
- 6. Pull both webbing shoulder straps in the back D-Ring tight against the black back plaque. (Figure 8)









Figure 8